



| N° | REFERENCE   | DESCRIPTION       |
|----|-------------|-------------------|
| 1  | 05TR0000226 | Mandrel M-6       |
| 2  | 05TR0000227 | Nosepiece M-6     |
| 3  | 05TR0000204 | Locknut           |
| 4  | 05TR0000202 | Nosepiece case    |
| 8  | 05BM0000204 | Main body         |
| 9  | 05BM0000205 | Screws + nuts     |
| 10 | 05BM0000206 | Handle (1 unit)   |
| 11 | 05TR0000215 | Expansion piece   |
| 12 | 05BM0000209 | Plates (4 units)  |
| 13 | 05BM0000207 | Piston            |
| 14 | 05TR0000214 | Adjustment nut    |
| 15 | 05BM0000210 | Anchoring pistons |
| 16 | 05BM0000211 | Mandrel collector |

| N° | REFERENCE   | DESCRIPTION       |
|----|-------------|-------------------|
| 17 | 05TR0000212 | Knob              |
| 18 | 05TR0000228 | Mandrel M-8       |
| 19 | 05TR0000229 | Nosepiece M-8     |
| 20 | 05TR0000230 | Mandrel M-10      |
| 21 | 05TR0000231 | Nosepiece M-10    |
| 22 | 05TR0000232 | Mandrel M-12      |
| 23 | 05TR0000233 | Nosepiece M-12    |
| 29 | 05BM0000100 | Nosepiece Spanner |
| 30 | 05BM0000109 | Wrench 12-18      |