




item	part no		qty	item	part no		qty
01	12001	head and handle	1	38	00401	spring	1
02	12002	rubber base	1	39	12300	deflector assembly	1
03	12003	end plug (screwed)	1	41	12103	plug	1
04	12004	O-ring	1	42	01274	oil plug	1
05	12005	piston rod fastening bolt	1	43	12043	oil seal washer	1
06	00134	O-ring	1	44	03021	suspension ring	1
07	00027	O-ring	1	45	12095	bridge washer	1
08	12008	O-ring	1	46	00420	M4 button socket hd screw	1
09	12009	pneumatic piston	1	47	12089	spring	1
10	12010	piston rod (intensifier)	1	48	12088	stroke setting finger	1
11	00205	spring	1	49	14049	seal	1
12	12012	air supply tube	1	50	14050	ring	1
13	12013	lock nut	1	51	14051	seal	1
14	12014	seal	1	52	14052	hydraulic piston	1
15	12015	rod guide	1	53	14053	spring	1
16	00100	O-ring	1	54	14054	shaft	1
17	12017	plug	1	55	14055	spring	1
18	12018	lip seal	1	56	14056	stroke stop	1
19	12019	guide	1	57	14057	screw	4
20	12020	trigger rod	1	58	14058	nut	1
21	00315	O-ring	1	59	14059	sleeve	1
22	12022	pin	1	60	14060	seal	1
23	12023	roller	1	61	14061	lock nut	1
24	12024	push wedge	1	62	14062	distributor	1
25	12025	trigger	1	63	14063	pin	1
26	12026	pin	1	64	14064	air supply tube	1
27	12027	valve locking plug	1	65	14065	O-ring	2
28	12028	valve piston	1	66	14066	screw	1
29	00086	O-ring	1	67	14067	spindle	1
30	00040	O-ring	1	68	14068	Adapter sleeve	1
31	00026	O-ring	1	69	14069	punzone	1
32	00046	O-ring	1	70	14070	nose casing	1
33	12033	1/8" nylon washer	1	71	14071	lock nut	1
34	12034	1/8" silencer	1	72	14072	matrice	1
35	14035	Air Inlet Assy	1	73	12084	circlip	1
36	00029	O-ring	1	74	12085	sintered silencer	1
37	12104	spring	1	75	12086	rear casing	1
				76	12087	rear casing rubber band	1