


No	Desc	Q'ty	No	Desc	Q'ty	No	Desc	Q'ty
1	Yoke Frame Plate	2	20	Cylinder	1	40	Allen Cap Screw	1
2	Wedge Guide Plate	2	21	Lever Shaft	1	41	Throttle Valve	1
3	Roller Thrust washer	4	22	Spacer Block Pin	1	42	"O" Ring	1
4	Plate Roller	2	23	Piston Return Spring	2	43	Throttle Valve Spring	1
5	Needle Roller	40	24	Piston Return Spring	2	44	Swivel	1
6	Roller shaft	2	25	Short "C" wedge	1	45	"O" Ring	1
7	Bearing Outer Race	1	27	Wedge Spacer Rivet	1	46	"O" Ring	1
8	Needle Roller	1	28	Piston Fork	1	47	Swivel Nut	1
9	Bearing Inner Race	1	29	Piston	1	48	Elbow	1
10	Lever Bearing Shaft	1	30	Piston Leather	2	49	Throttle Valve Lever	1
11	Set Holder Lever	1	31	Piston Leather Plate	2	50	Piston Rod	1
12	Yoke Bolt	2	32	Piston Rod Nut	1	51	Return Ring	2
13	Yoke Bolt Nut	2	33	Cylinder Head Gasket	1	52	O-Ring	1
14	Lever Shaft Screw	1	34	Cylinder Head	1	53	Separator	1
15	Lever Shaft Washer	1	35	Throttle valve Bushing	1	54	O-Ring	1
16	Spacer Block	1	36	"O" Ring-Brass Bushing	1	55	Tandem Piston	1
17	Set Screw	1	37	Spring	1	56	Set Holder	1
18	Guard	1	38	Lever Arm	1	57	Set Holder Spring	1
19	Guard Screw	1	39	Screw	1			

IRIVET
Компания АЙРИВЕТ
ООО "АЙ-РИВЕТ"
www.irivet.ru
Тел: +7 (495) 135 4201
Тел: +7 916 922 6789
Почта: order@irivet.ru
AIR PRO